

Leg & Caster Options



1004 Leg

4 in. high (front) - 3 in. high (back) | 5 1/2 in. wide



1201 Leg

4 1/2 in. high | 6 in. wide



2404 Leg

6 in. high | 6 in. wide



2504 Leg

4 1/2 in. high | 5 in. wide



101 Bun Foot

3 3/4 in. high | 4 1/2 in. wide



894 Pyramid Leg

3 3/4 in. high | 4 1/4 in. wide



2104 Wide Pyramid Leg

3 in. high | 5 1/2 in. wide



342 Leg

5 1/2 in. high | 4 1/2 in. wide



Stob Leg

2 in. high | 2 in. wide



54 Leg

4 in. high | 3 in. wide



55 Leg

4 in. high | 4 in. wide



66 Leg

5 1/4 in. high | 4 1/4 in. wide


Leg & Caster Options



351 Leg
6 1/4 in. high | 2 3/4 in. wide



3401 Leg
6 1/4 in. high | 3 1/2 in. wide



7114 Tapered Leg
3 in. high | 4 1/4 in. wide



4174 Leg
6 in. high | 2 1/2 in. wide



4224 Leg
6 in. high | 2 1/2 in. wide



4200 Leg
1 3/4 in. high | 6 in. wide



CA1 Brass Sofa Caster
2 in. high | 2 in. wide



CA2 Rubber Ball Caster
(Conference Chairs)
2 1/4 in. high | 2 1/4 in. wide



CA3 Double Wheel Caster
(Swivel Chairs)
2 1/4 in. high | 2 1/4 in. wide



CA4 Brushed Nickel Ferrule\Caster
Overall: 2 1/2 in. high | 1 in. wide
Caster: 1 1/4 in. high



CA4 Antique Brass Ferrule\Caster
Overall: 2 1/2 in. high | 1 in. wide
Caster: 1 1/4 in. high